

THE INSTALLATION OF HP14 CHIP

Ink Cartridge No.: C5011A and C5010A

To Use in: Color inkjet 1160/Officejet
7110/7110A2L/7110xi/7130/7130xi/7140xi/D125xi/D135/D145/D155xi

Installation:

1. The chip as below:



2. Prize up the original PCB.



3. Pull apart the paper in the pcb as below:



4. Stick the pcb and the finished ink cartridge as below:

