

Instruction for Epson C80 Refillable Cartridge




Pull the rubber seal out of the Ink Filling Hole.



Use 60ml Syringe draw about 30ml ink.



Insert the syringe into the Ink Filling Hole of the cartridge. Make sure that they join well, and no air leaks at the joint point.



Draw the plunger upward.



Draw about 20ml air.



Loosen the plunger, and the ink will be pressed into the cartridge naturally. Pls don't press the plunger directly. Otherwise the ink will splash.



Repeat the above procedures and fill the cartridge full with ink.



After finish filling, then recover the plugs into the Ink Filling Hole. When you use it in the printer, pls take the plugs out of the Air Hole.